

· Tripack clear lens

· Tripack orange lens

Tripack



Prescription eye protection

Description and composition:

Sport-design versatile spectacles thanks to three pairs of interchangeable lenses in three tones: clear, solar and orange. Lenses are easily extracted.

Removable temples with non-slip ends.

Cushioned interior front that gives the spectacles higher protection from impacts and particle penetration.

Includes a non-flammable adjustable elastic strap: the strap is used to replace the temples. Mainly for activities that, due to movement, can cause spectacles loss, as well as for general sport use.

Temples may be removed by pressing the "button" at the joint and pulling outwards. To reinsert the temples, just slot them back in and push. The strap is attached and removed in the same way.

Includes an easily attached prescription lens supplement that can be used for monofocal polycarbonate or organic lenses.

Comes in a rigid case with three pairs of interchangeable lenses, the adjustable strap and the prescription lens supplement (without prescription).

Colour:

Weight: 30 g



Temples replaceable with strap



Prescription lens supplement



Served in case

	_			
Base: 7	Base: 7		MARKING	
Ref.	Product		Frame	Lenses
	Complete tripack with	Clear spectacles. Anti-fogging and anti-abrasion treatment cert.	2C-1.2 M 1 FT K N CE	
911174	adjustable clip,	Solar spectacles. Anti-fogging and anti-abrasion treatment cert.	5-3.1 M 1 FT K N CE	M EN166 FT CE
	rubber and case:	Orange spectacles. Anti-fogging and anti-abrasion treatment cert.	2C-1.2 M 1 FT K N CE	
911242	2 Prescription lens supplement		CE	M EN166 FT CE
912044	Solar Replacement lens. Anti-fogging and anti-abrasion treatment cert.		5-3.1 M 1 FT K N CE	M EN166 FT CE
912045	Clear Replacement lens. Anti-fogging and anti-abrasion treatment cert.		2C-1.2 M 1 FT K N CE	M EN166 FT CE
912047	Orange Replacement lens. Anti-fogging and anti-abrasion treatment cert.		2C-1.2 M 1 FT K N CE	M EN166 FT CE

Prescription eye protection

Standard and certification	EN 166 / EN 172 / EN 170	
Applications	Protects from impacts at high velocity at extreme temperatures (FT marking). Protects against solar radiation (solar version) and UV radiation (clear and orange versions). Certification as anti-fogging (N marking) makes them appropriate for activities where there are rapid changes in temperature and/or humidity levels. Sectors: agricultural activities, forestry, automotive industry, textiles, plastics, sport and outdoor activities. The orange version is adequate for activities in low light conditions or that require sharper vision.	
Conservation Storage - Expiry	In order to maintain the spectacles in good condition, keep them in a clean, dry place in their appropriate case.	
Directions Use	Cleaning: use warm water and a neutral soap. Do not use abrasives or solvents. Rinse in water and dry with a soft cloth. Medop anti-fogging cleaning spray is also recommended. We advise regular inspection of the protectors, and their replacement if they have deteriorated.	
	in any way. Please ensure that the risk present in the workplace corresponds with the field of use of these protectors.	
Presentation	in any way. Please ensure that the risk present in the workplace corresponds with the field of	
Presentation Bar code	in any way. Please ensure that the risk present in the workplace corresponds with the field of use of these protectors. NEUTRAL sale units: 1 unit case. 10 cases per carton. (Prescription lens spectacles: no minimum units required) 911174 GIN-13: 8423173871680 GIN-14: 18423173871687	
TAIPACK	in any way. Please ensure that the risk present in the workplace corresponds with the field of use of these protectors. NEUTRAL sale units: 1 unit case. 10 cases per carton. (Prescription lens spectacles: no minimum units required) 911174 GIN-13: 8423173871680 GIN-14: 18423173871687 911242 GIN-13: 8423173872083 GIN-14: 18423173872080	
TAIPACK	in any way. Please ensure that the risk present in the workplace corresponds with the field of use of these protectors. NEUTRAL sale units: 1 unit case. 10 cases per carton. (Prescription lens spectacles: no minimum units required) 911174 GIN-13: 8423173871680 GIN-14: 18423173871687	

